




Breville®

BES980




OPEN TOP COVER AND ACCESS MAIN PCB



This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

HOW TO OPEN TOP COVER AND ACCESS MAIN PCB?		
1.	Remove 2 screws near shower head as indicated.	
2.	Remove 4 screws of rear top cover. Note: Screw marked by arrow is longer than the other screws.	
3	Remove the top and top rear cover	

This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

4.	Remove 2 screws of bottom cover. Note: Screw marked by arrow is longer than the other screw.	
5.	Remove 4 screws of Main PCB assembly (2 on the top and 2 on the bottom.)	
6.	Unlock the locking tabs as indicated to access main PCB.	
7.	Reassemble: Reverse the procedure from Step 6.	

This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group