

Breville®





BES980

REPLACE STEAM WAND ASSEMBLY







This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group





Steam wand Assembly replacement

1.	Remove 2 screws near shower head as indicated.	
2.	Remove 4 screws of rear top cover. Note: Screw marked by arrow is longer than the other screws.	
3.	Remove the top and top rear cover	
4.	Open top Housing and fold it to rear side.	






This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

5.	Remove Cable Tie above Steam Wand Assembly.	
6.	Remove the Close-end Connector (as mark by red circle) and disconnect wires. Remember 1 is red wire, and 2 white wires connected.	
7.	Remove cable tie from top of Steam Boiler. (as mark by red circle)	
8.	Remove 3 Cable Ties from Main Chassis (at the side of Steam Dial).	


This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

9.	<p>A. Remove 2 cable ties as mark by red circle.</p> <p>B. Remove 2 Screws from Bottom cover.</p> <p>C. Disassemble Rear Panel Cover Bottom and fold to the side.</p>	
10.	<p>Remove the Close-end Connector and disconnect black and green wire.</p>	
11.	<p>Release 2 tap at PCB box for open the PCB top cover.</p>	
12.	<p>Remove Blue female connector from PCB as mark by Red circle.</p>	

This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

13.	Remove 3 Screws from Hinge Bracket of Steam Wand Assembly.	
14.	Disconnect Earth Wire from Americano Solenoid Valve.	
15.	Disconnect the Earth Wire from Steam Solenoid Valve.	
16.	Remove the earth connection form steam boiler Bracket (Pay attention to the 4pcs Spring Washers between the Round Terminals)	
17.	A. Remove U-Shape Clip and disconnect Teflon tube from Venturi Outer. B. Remove the O-Ring from the Teflon tube (or Venturi Outer). C. Replace the Teflon tube O- Ring.	

This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group

18.	<p>A. Hold and push Steam Wand Assembly upward.</p> <p>B. Replace new Steam Wand Assembly</p>	
19.	<p>Reassemble: - Reverse the procedure from Step 18.</p>	

This document is the property of Breville Group which contains confidential and propriety information and is a reference document to be used only by the intended recipient and not shared with other parties. No part of the information may be used or reproduced in anyway without the written consent of Breville Group